

- Não apoiar a TV

ACESSÓRIOS | ACCESSORIES | ACCESORIOS

A x5 PARAFUSO MINIFIX MINIFIX SCREW	B x20 CAVILHA 6X30 WOOD DOWEL 6X30	C x18 PARAFUSO 3,5X50 SCREW 3,5X50	D x11 PARAFUSO 6,0X60 SCREW 6,0X60	E x1 PARAFUSO 5,5x65 SCREW 5,5x65	F x34 PARAFUSO 3,5x10 SCREW 3,5x10
G x15 PARAFUSO 4,5X22 SCREW 4,5X22	H x7 PARAFUSO 4,0X60 SCREW 4,0X60	I x12 BUCHA UX 8X50 PLUG UX 8X50	J x5 TAMBOR CAM LOCK	K x3 PASSA FIO DESK GROMMET	L x5 DISPOSITIVO DEVICE
M x3 DISTANCIADOR DISTANCER	N x3 TAPA FURO TAPA HOLE STICKERS	O x6 CHAPA 46X46 SHEET 46X46	P x6 PINO GUIA GUIDE PIN	Q x1 TRILHO 1460 RAIL 1460	R x2 COLA GLUE
S x1 KIT PORTA DE CORRER SLIDING DOOR KIT					

Início da Montagem | Assembly Start | Inicio del Ensamble | Début du Montage

1º Passo
Pass / Paso / 1er étape

2º Passo
Pass / Paso / 2er étape

3º Passo
Pass / Paso / 3er étape

5º Passo
Pass / Paso / 5er étape

4º Passo
Pass / Paso / 2er étape

VIDEO MONTAGEM DA PORTA
VÁ PARA O MINUTO 6:25 PARA O PASSO DA MONTAGEM DA PORTA

DOOR ASSEMBLY VIDEO
GO TO MINUTE 6:25 FOR DOOR ASSEMBLY STEP

6º Passo
Pass / Paso / 6er étape

7º Passo
Pass / Paso / 7er étape

8º Passo
Pass / Paso / 8er étape

9º Passo
Pass / Paso / 9er étape

10º Passo
Pass / Paso / 10er étape

11º Passo
Pass / Paso / 11er étape

12º Passo
Pass / Paso / 12er étape

13º Passo
Pass / Paso / 13er étape

13B

13A

13C

13D



ESCANEE AQUI